TS ARAX 2.8/80 PHOTOGRAPHIC LENS

Operations manual

1. GENERAL GUDIELINES

The TS ARAX 2,8/80 (TS = Tilt Shift) compact lens with tilt and shift movements is a six element (5 group) optical system, suited to make unique optical effects during photo and video shooting. The effects of large-format camera movements can be obtained with small TS ARAX lenses for 35mm cameras.

The TS ARAX 2,8/80 lens is produced for for 35mm type cameras:

- Nikon F (AI, AIs)
- Canon EOS
- Canon FD
- Minolta Dynax
- Minolta MD
- Pentax K
- M42 (Zenit, Practica, etc.)
- Olympus OM1 ... OM3
- Contax
- Yashica
- Sony Alpha

The block of tilt shifting mechanism is designed to provide the power to correct the optical line of the lens. For example, to correct the distortions encountered during shooting architecture or to make more deep of focus pictures.

The optical elements of the lens have a special seven layer coating (MC), they improve image quality and increase contrast range by enhancing integral transmission and decreasing the dispersion.

The camera lens operates in the temperature range from minus 15 to 50° C.



2. TECHNICAL SPECIFICATIONS

- Image ratio, mm: 24x36
- Focal distance, mm: 80
- Aperture ratio: 1:2,8
- Design: 6 elements, 5 groups
- Angle of view without shifting optical block: 45°
- Short focusing range, m: 0,6
- Aperture range: 2,8 22
- Aperture operation: Manual
- Threads for light filters, mm: 62
- Maximum shift of the optical block, mm: 11
- Maximum tilt of the optical block: 8°
- Turning angle of the optical block relative to bayonet axis: 360°
- Maximal diameter, mm, not more than: 72
- Overall dimensions, mm, not more than: 82x87
- Weight, kg, not more than: 0,85



Figure 1, TS plate dimensions



Figure 2



Figure 3

Focusing ring 1.

5.

- Distance scale 2. Deep of field scale 3.
- Tilt scale 8.

6

7.

- 4. Aperture ring/scale Aperture on/off ring
- 9. 360° rotating ring 10. Shift handle

TS plate

Tilt handle

Shift scale 11.

3. OPERATIONS INSTRUCTIONS

3.1. Lens installation on the camera and its removal

Install and remove the lens as it written in the camera's operation manual.

3.2 Focusing

It is preferable to perform focusing at maximum aperture by rotating the focusing ring 1, on which focusing scale (distance) 2 is marked.

When focusing the lens after it has been shifted, it is possible that the microprism and the split-image rangefinder of the viewfinder of the camera may darken. In that case, check the image sharpness on the matte spot of the focusing screen. Orientation based on a distance scale 2 after the lens has been shifted shall not give precise result.

During optical block tilting and shifting, decrease the aperture as far as possible, because unequal amounts of the light falls on the edges and center of the field. It is recommended to use the aperture values from 16 to 22.

3.3. Aperture operation

The lens aperture are fully manual. Select the aperture by the ring 4. You can use also the aperture on/off control ring 5 when you want to wide open the aperture for focusing and return to the selected aperture. You can do it rotating the ring 5 from side to side.

3.4. Lens shifting

While rotating handle 10, the lens is moving in parallel to the image surface. The lens can be rotated by 360° with settled interval every 30° (the lens can operate even in the positions between these intervals). Due to the fact that the camera's image is rectangular, the limit degree of lens shift will be changing at every rotation. The maximal shift is possible at the settled position of the lens along the image's short side. Control this shift on the scale 11.

3.5. Lens tilting

While rotating tilting handle 7, the lens is tilting. Tilting depends from the direction of rotation of tilting handle 7. The lens can be rotated by 360° with settled interval every 30° (the lens can operate even in the positions between these intervals). Due to the fact that the camera's image is rectangular, the limit degree of lens tilt will be changing at every rotation. The maximal tilt is possible at the settled position of the lens along the image's short side. Control this shift on the scale 9. Remember that it is recommended to set up the tilt angle with the zero position of the shift.

Tilting during photographing, obey the Scheimpflug principal, which states that if a lens is tilted such that the lens plane intersects the film plane, the plane of sharp focus must also pass through that same line of intersection like it shown on the scheme below.



3.6. Lens rotating

The lens can be rotated by 360° with settled interval every 30° (the lens can operate even in the positions between these intervals). For 360° lens rotating just rotate the ring 9 clockwise or counter-clockwise. When lens installed on the camera body, you can rotate them also holding lens body or TS plate 6.

3.7. Distortion correction

When photographing high buildings from ground level, the distances from the lens from the top and bottom of the subject are radically different. As a result of this, the distortion in this case appears as a convergence of the parallel lines upwards (Figure 4), and vice versa: when photographing from above downwards, the parallel sides of the building will be converging downwards.



Figure 4

In order to correct such distortion do not incline the camera either upwards or downwards, but maintain the film plane in parallel to the object being photographed (for example, building), thus that film plane of the camera is situated at right angles to the ground. Then, in order to achieve the intended composition the optical block of the lens shall be shifted vertically upwards, due to this the distortion is eliminated. See Figure 5.



Sometimes instead of image correction, with the intention of creating special effects, the occasion arises to create even more exaggerated distortions. In this case, you would incline the camera upwards and shift the lens in the opposite direction.

3.8. Reflection elimination

When photographing objects with reflective surfaces, the reflection of the photographer along with camera can appear on the image. (Figure 6A). Carrying over the camera angle to one side and shifting the lens to the opposite side, while retaining the parallelism of the object and film planes allows you to eliminate the reflection and still preserve the rectangular composition of the image (Figure 6B).



3.9. Panoramas

While using a lens with shift capability you can produce panoramic photographs. For that, make two exposures from one camera angle: first one – with maximum shift of the lens to the right, and a second one – with maximum shift to the left. Combining both images will provide you with a single panoramic photograph (Figure 7), which corresponds to a negative with an image format of 6x9 cm and normal perspective.



3.10. Obstruction elimination

Obstructions like trees or telegraph poles located relatively closely to the camera and appearing at the image edge can be eliminated by means of lens shifting and rotating the camera.

For instance, the obstruction (pole) is located at the image edge on the right. See Figure 8A. To eliminate it, shift the lens to the right, and rotate the camera to the left until full disappearance of the pole. (Figure 8B).



4. STORAGE AND MAINTENANCE RULES

The camera lens is a complicated optical device and it requires careful operation and maintenance. Protect it against impacts, sudden fluctuations in temperature and also against dust and moisture.

Upon entrance into a warm room from outside frost do not open the lens immediately. Let it warm up to prevent condensation on the optical surfaces.

Remove dust and moisture from the lens with a soft brush, cloth, or a product specific to this purpose.

Note: During inspection it can be found out that some lenses may have small bubbles in the glass, insignificant scratches and fluffs which do not in any way affect image quality and have been accepted by the ARAX standard.

Version 4 (08-08-2017)

Kiev, Ukraine www.araxfoto.com info@araxfoto.com